



BAGMANE

Bagmane Developers Pvt. Ltd.
Integrated Management System
Hydrant Pump Daily Checklist

Document Number: BDPL OCP 02 F-07

Revision Date: January 16, 2024

Rev. No.: 02

Building:																			Wing:	Month:																		
Hydrant Pump No:			Hydrant Pump Make:															Hydrant Pump Rating:																				
Sl. No.	Description	Spec	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31					
Cleaning:																																						
1	Clean the pump and its base Frame	Free from dirt																																				
2	Clean the Pipe up to 6" height	Free from dirt																																				
3	Clean the pump Panel	Free from dirt																																				
Inspection:																																						
1	Check pump bearing noise & abnormal temp.	Noise free and normal temp																																				
2	Check pump SUCTION & DISCHARGE line valve - OPEN/CLOSE	Should be open																																				
3	Check pump GLAND packing & mechanical seal.	Leak free																																				
4	Check the coupling condition of the motor	No damage & looseness																																				
5	Check the coupling guard condition of the motor	Tightened																																				
6	Check the tightness of the motor base bolts & nuts.	By match marking																																				
7	Check pump control panel condition & selection switch position.	Auto																																				
8	Clean the pump room floor with HK team.	Free from dirt																																				
9	Remove any unwanted material laying in the floor.	Free from debris																																				
Fire Technician sign.																																						
Maintenance sup. Sign.																																						
Remarks:																																						
															BIC / AFM Sign.																							