



BAGMANE

Bagmane Developers Pvt. Ltd.

Integrated Management System

Sprinkler Pump Daily Checklist

Document Number: BDPL OCP 02 F-10

Revision Date: January 16, 2024

Rev. No.: 02

Building:

Wing:

Sprinkler Pump No:

Sprinkler Pump Rating:

Month:

Sl. No.	Description	Spec	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31
---------	-------------	------	---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----

Cleaning:

1	Clean the pump and its base frame	Free from dirt																													
2	Clean the Pipe up to 6 " height	Free from dirt																													
3	Clean the pump panel	Free from dirt																													

Inspection:

1	Check pump bearing noise & abnormal temp.	Noise free and normal temp																													
2	Check pump SUCTION & DISCHARGE line valve - OPEN/CLOSE	Should be open																													
3	Check pump GLAND packing & mechanical seal.	Leak free																													
4	Check the coupling condition of the motor	No damage & looseness																													
5	Check the coupling guard condition of the motor	Tightened																													
6	Check the tightness of the motor base bolts & nuts.	By match marking																													
7	Check pump control panel condition & selection switch position.	Auto																													
8	Clean the pump room floor with HK team.	Free from dirt																													
9	Remove any unwanted material lying on the floor.	Free from debris																													

Fire Technician sign..

Maintenance Sup. Sign..

Remarks:

BIC / AFM Sign.