



BAGMANE

Bagmane Developers Pvt. Ltd.

Integrated Management System

Booster Pump Daily Checklist

Document Number: BDPL OCP 02 F-08

Revision Date: January 16, 2024

Rev. No.: 02

																									Wing:								
Booster Pump No:			Booster Pump Rating:																							Month:							
Sl. No.	Description	Spec	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31
Cleaning:																																	
1	Clean the pump and its base frame	Free from dirt																															
2	Clean the Pipe up to 6 " height	Free from dirt																															
3	Clean the pump panel	Free from dirt																															
Inspection:																																	
1	Check pump bearing noise & abnormal temp.	Noise free and normal temp																															
2	Check pump SUCTION & DISCHARGE line valve - OPEN/CLOSE	Should be open																															
3	Check pump GLAND packing & mechanical seal.	Leak free																															
4	Check the coupling condition of the motor	No damage & looseness																															
5	Check the coupling guard condition of the motor	Tightened																															
6	Check the tightness of the motor base bolts & nuts.	By match marking																															
7	Check pump control panel condition & selection switch position.	Auto																															
8	Clean the pump room floor with HK team.	Free from dirt																															
9	Remove any unwanted material lying on the floor.	Free from debris																															
Fire Technician sign.																																	
Maintenance Sup. Sign.																																	
Remarks:																																	
															BIC / AFM Sign.																		